



Panic Button

1. Panic / Learn Button
2. LED Indicator

Przycisk napadowy

1. Przycisk napadowy/adaptacji
2. Dioda LED

ENGLISH

Getting Started

1. Loosen the screw at button to open back cover, insert the battery provided and close the back cover.
2. Put the Control Panel into learning mode.
3. Press and hold the button for about 3 seconds to learn the Panic Button.
4. Refer to Control Panel manual to complete learning process.

Mounting Location

- Mount in a convenient location for easy access, such as living room or bedroom

Operation

- Press and hold the button for 3 seconds to activate a Panic alarm regardless of system mode.
- The LED will light up when the button is pressed.

Installation

1. Break through knockouts on back cover.
 2. Drill holes into wall using the knockouts as template.
 3. Fix the back cover onto the wall with screws and plugs provided.
 4. Replace the front cover on the back cover
- Instead of screw mounting, you can also use the double side adhesive tape included in the package to install the accessory.

Battery

The Panic Button uses one **CR2032 3V** lithium battery. It features low battery detection function to notify the Control Panel when battery voltage is low.

When the Panic Button is on low battery, follow the procedure below to change the batteries.

1. Open the back cover
2. Remove the old battery
3. Insert the new batteries observing correct polarity
4. Replace the back cover.

Specification

Environmental Condition:

-10 °C to 40 °C, relative humidity 85% non-condensing.

Radio:

868 MHz

POLSKI

Pierwsze kroki

1. Poluzuj śrubę przycisku napadowego, aby otworzyć tylną pokrywę. Włóż baterię dołączoną do zestawu i zamknij tylną pokrywę.
2. Wprowadź Panel sterowania w tryb adaptacji.
3. Aby dodać przycisk napadowy do systemu, wciśnij go, a następnie przytrzymaj przez 3 sekundy.
4. W celu przeprowadzenia procesu adaptacji zapoznaj się z instrukcją obsługi Panelu sterowania.

Umiejscowienie urządzenia

- Umieść w wygodnym miejscu zapewniającym łatwy dostęp takim, jak salon czy sypialnia.

Obsługa

- Aby aktywować alarm napadowy bez względu na tryb pracy systemu, wciśnij, a następnie przytrzymaj przycisk napadowy przez 3 sekundy.
- Po wciśnięciu przycisku zapali się dioda LED.

Montaż

1. Zdejmij zaślepki znajdujące się w tylnej pokrywie.
 2. Wywierć otwory w ścianie, wykorzystując zaślepki do pomocy.
 3. Przymocuj tylną pokrywę do ściany za pomocą dołączonych wkrętów i kołków.
 4. Umieść pokrywę przednią na pokrywie tylnej.
- Urządzenie możesz przymocować nie tylko za pomocą śrub, ale i dwustronnej taśmy klejącej dołączonej do zestawu.

Bateria

Przycisk napadowy zasilany jest baterią litową **CR2032 3 V**. Przycisk napadowy posiada funkcję wykrywania niskiego stanu baterii i przekazywania odnośnych informacji do Panelu sterowania.

W przypadku niskiego poziomu baterii przycisku napadowego postępuj zgodnie z poniższą procedurą.

1. Otwórz pokrywę tylną.
2. Usuń starą baterię.
3. Włóż nowe baterie, zwracając uwagę na prawidłową biegunowość.
4. Umieść pokrywę tylną na miejscu.

Specyfikacja

Warunki otoczenia:

od -10°C do 40°C, wilgotność względna 85% brak kondensacji.

Częstotliwość radiowa:

868 MHz